# UART Communication (TXD0, RXD0, TXD2, RXD2 Pins)




Figure 1: ESP32 UART Communication Pins

The ESP32 supports multiple UART (Universal Asynchronous Receiver/Transmitter) interfaces for serial communication. On the ESP32-WROOM, the default communication interface with the computer (via USB) uses TXD0 (GPIO1) and RXD0 (GPIO3), while another commonly used interface is TXD2 (GPIO17) and RXD2 (GPIO16).

### What are TXD and RXD Pins?

- TXD (Transmit Data): Sends serial data out of the ESP32.
- RXD (Receive Data): Receives serial data into the ESP32.

### Default UART Pins

- TXD0 (GPIO1) Transmit pin used for programming/debugging via USB.
- RXD0 (GPIO3) Receive pin used for programming/debugging via USB.
- These are connected internally to the USB-to-UART bridge chip, enabling uploading of code and printing logs with Serial.print().

### Additional UART Pins

• TXD2 (GPIO17) – Transmit pin of UART2, available for user applications.

- RXD2 (GPIO16) Receive pin of UART2, available for user applications.
- Commonly used to connect external devices such as:
  - GPS modules
  - GSM/GPRS modules
  - Bluetooth modules (HC-05, HC-06)
  - Communication with other microcontrollers

### ESP32 UART Features

- The ESP32 has 3 UART controllers:
  - UART0: TXD0 (GPIO1), RXD0 (GPIO3) default programming/debugging.
  - **UART1:** User-configurable pins (no fixed default).
  - UART2: TXD2 (GPIO17), RXD2 (GPIO16) available for peripherals.
- Baud rates supported: up to 5 Mbps.
- UART pins can be re-mapped to different GPIOs using software if needed.

## Example Usage

When using Serial.begin(115200); in Arduino IDE, the ESP32 communicates through TXD0 (GPIO1) and RXD0 (GPIO3).

If you want to communicate with an external module like a GPS via UART2, you can use:

```
HardwareSerial mySerial(2);
mySerial.begin(9600, SERIAL_8N1, 16, 17); // RX=16, TX=17
```

This initializes UART2 using RXD2 (GPIO16) and TXD2 (GPIO17) for serial communication.